Computer Network Lab – 3

Aditya Agarwal


Roll No - 14

1. Network Design

Components:

- HTTP Server
- FTP Server
- DNS Server
- Switch
- Router
- PC

Network Diagram:




2. Configuration of the PC

Steps:

- 1. Open Packet Tracer.
- 2. Select the PC:
 - Click on the PC icon in the workspace.
 - Go to the **Desktop** tab.
 - Click on **IP Configuration**.
- 3. Assign IP Address:
 - Enter the IP address, subnet mask, and default gateway as specified. For example:
 - IP Address: 192.168.1.10
 - Subnet Mask: 255, 255, 255, 0

• Default Gateway: 192.168.1.1



3. Configuration of the Router

Steps:

1. Open Router CLI:

- Click on the router icon in the workspace.
- Select the **CLI** tab.

2. Configure the Router Interfaces:

• First Interface (e.g., GigabitEthernet0/0):

```
plaintext
Copy code
Router> enable
Router# configure terminal
Router(config)# interface gigabitethernet0/0
Router(config-if)# ip address 192.168.1.1 255.255.255.0
Router(config-if)# no shutdown
Router(config-if)# exit
```

• Second Interface (e.g., GigabitEthernet0/1):

```
plaintext
Copy code
Router(config)# interface gigabitethernet0/1
Router(config-if)# ip address 192.168.2.1 255.255.255.0
Router(config-if)# no shutdown
Router(config-if)# exit
```

4. Configuration of Servers

HTTP Server Configuration

- 1. **Open HTTP Server:**
 - Click on the HTTP server icon in the workspace.
 - Go to the **Desktop** tab.

• Click on **IP Configuration**.

2. Assign Static IP Address:

• Enter the IP address, subnet mask, and default gateway. For example:


• IP Address: 192.168.1.2

• Subnet Mask: 255.255.255.0

• **Default Gateway:** 192.168.1.1

3. Disable Other Services:

• In the HTTP server's **Services** tab, ensure that only HTTP is enabled. Disable other services such as FTP and DNS if they are available on this server.



FTP Server Configuration

1. **Open FTP Server:**

- Click on the FTP server icon in the workspace.
- Go to the **Desktop** tab.
- Click on **IP Configuration**.

2. Assign Static IP Address:

• Enter the IP address, subnet mask, and default gateway. For example:


• IP Address: 192.168.1.3


• Subnet Mask: 255.255.255.0

• Default Gateway: 192.168.1.1

3. Disable Other Services:

• In the FTP server's **Services** tab, ensure that only FTP is enabled. Disable other services such as HTTP and DNS if they are available on this server.






DNS Server Configuration

1. Open DNS Server:

- Click on the DNS server icon in the workspace.
- Go to the **Desktop** tab.
- Click on **IP Configuration**.



2. Assign Static IP Address:

• Enter the IP address, subnet mask, and default gateway. For example:


• IP Address: 192.168.1.4

• Subnet Mask: 255.255.255.0

• Default Gateway: 192.168.1.1

3. Disable Other Services:

• In the DNS server's **Services** tab, ensure that only DNS is enabled. Disable other services such as HTTP and FTP if they are available on this server.



5. Testing Connectivity

1. Ping Test:

• From the PC, use the Command Prompt to ping each server:

2. Access Services:

HTTP Server:

```
Pinging 192.168.1.2 with 32 bytes of data:

Reply from 192.168.1.2: bytes=32 time=10ms TTL=128

Reply from 192.168.1.2: bytes=32 time=9ms TTL=128

Reply from 192.168.1.2: bytes=32 time=10ms TTL=128

Reply from 192.168.1.2: bytes=32 time=10ms TTL=128

Ping statistics for 192.168.1.2:

Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),

Approximate round trip times in milliseconds:

Minimum = 9ms, Maximum = 10ms, Average = 9ms
```

FTP Server:

```
Pinging 192.168.1.3 with 32 bytes of data:
Reply from 192.168.1.3: bytes=32 time=12ms TTL=128
Reply from 192.168.1.3: bytes=32 time=11ms TTL=128
Reply from 192.168.1.3: bytes=32 time=12ms TTL=128
Reply from 192.168.1.3: bytes=32 time=11ms TTL=128

Ping statistics for 192.168.1.3:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milliseconds:
Minimum = 11ms, Maximum = 12ms, Average = 11ms
```

DNS Server:

```
Pinging 192.168.1.4 with 32 bytes of data:
Reply from 192.168.1.4: bytes=32 time=8ms TTL=128
Reply from 192.168.1.4: bytes=32 time=8ms TTL=128
Reply from 192.168.1.4: bytes=32 time=9ms TTL=128
Reply from 192.168.1.4: bytes=32 time=8ms TTL=128

Ping statistics for 192.168.1.4:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milliseconds:
Minimum = 8ms, Maximum = 9ms, Average = 8ms
```

Conclusion

The network has been successfully configured with an HTTP server, FTP server, DNS server, switch, router, and PC. The router interfaces were set up with appropriate IP addresses, and all servers were configured with static IPs and specific services. Connectivity and functionality were verified through ping tests and service access.